


MAINTENANCE PROCEDURES
Mirra Commercial Flooring

First Cleaning After Commercial Installation

1. After installation when the adhesive is fully cured (see "Curing Times" below) perform with the initial cleaning of the floor.
2. Remove surface dust and soil particles by using a vacuum or brush.
3. Clean the floor with a wet mop and a solution Wood Wyant Pathfinder Low Foam Neutral Cleaner. For stubborn, ingrained dirt, scrub the floor using a solution of Wood Wyant Pathfinder Low Foam Neutral Cleaner and a 175 to 350 R.P.M. scrubbing machine equipped with a red fiber pad or nylon brush.
4. Use a wet vacuum or a mop to absorb the residue.
5. Rinse with cold water. Do not flood the floor. Use a wet vacuum or mop to absorb the water.
6. Let the floor dry completely. Your new Mirra flooring is ready to use.

OPTIONAL:

7. To create a higher luster proceed to spray buff using Wood Wyant Quicksnap Multispeed Spray Buff. Use a 175 to 350 R.P.M. buffer equipped with a white pad.

CURING TIMES

Site conditions can greatly affect curing times of the adhesives. Visually check the tile installation to make sure curing of the adhesive is happening by pulling back the corner of the tile. If it will not peel back easily the curing process is underway. This must not be attempted prior to 24 hours following installation.

We recommend the following adhesive curing guidelines for #530SF adhesive:

- Up to 24 hours following installation – no traffic
- Between 24 to 48 hours – light traffic
- After 72 hours – moderate to heavy traffic, placement of furniture and rolling traffic.

We recommend the following adhesive curing guidelines for AD-444 adhesive:

- Up to 12 hours following installation – no traffic
- Between 12 to 72 hours – light traffic
- After 72 hours – moderate to heavy traffic, placement of furniture and rolling traffic.

Regular Cleaning

Remove surface dust and soil particles by daily sweeping or vacuuming. If necessary, clean with a wet mop using Wood Wyant Pathfinder Low Foam Neutral Cleaner.

Periodic Cleaning (as required)

1. Clean the floor with a damp mop and Wood Wyant Pathfinder Low Foam Neutral Cleaner.

OPTIONAL:

2. Proceed to spray buff using Wood Wyant Quicksnap Multispeed Spray Buff. Use a 175 to 350 R.P.M. buffer equipped with a white pad.

These installations and care recommendations are provided as assistance only. We do not assume responsibility for actual work performed. The warranty extends only to the quality and performance of Mirra flooring.

Types of Pads and Uses

- White pads used for polishing
- Red pads used for light scrubbing
- Soft nylon brush

Note: For additional care and maintenance instructions you may contact WOOD WYANT INC. Customer Service directly at 1-800-361-7691

