



# Marathon Oasis & Dura-MED Rolled Rubber

## MAINTENANCE INSTRUCTIONS

### FIRST CLEANING AFTER INSTALLATION

#### SAFETY FIRST:

Before starting any maintenance procedures make sure all safety precaution are in position such as posting “ Caution” and “Wet/Slippery” Flooring signs.

#### IMPORTANT:

Before proceeding to set up your floor, read all instructions carefully and make sure the adhesive has fully cured (Refer to “Installation Instructions for Curing Time guidelines”).

#### START-UP FLOOR MAINTENANCE:

Do not start any maintenance procedures for a minimum of seven (7) days following installation.

**DO NOT AT ANY TIME DURING THE INITIAL MAINTENANCE OR THEREAFTER FLOOD THE FLOOR WITH WATER OR MAINTENANCE SOLUTIONS.**

#### Initial Maintenance After Installation

1. Remove surface dust and soil particles by using a vacuum or brush.
2. Prepare a mixture of TASKI Profi or JohnsonDiversey Profi and water (225 ml (8 ounces) TASKI Profi or JohnsonDiversey Profi per 4 liter (1 gallon) of warm water). Spread the solution evenly over the floor using a mop or sponge. **Do not flood the floor** and do not allow the solution to dry onto the floor. Wait 5 to 10 minutes before proceeding with the cleaning.
3. Scrub the floor using a 175 to 350 R.P.M. buffing machine equipped with a red fiber pad or soft nylon brush.
4. Use a wet vacuum or a mop to absorb the residue.
5. Rinse with cold water. Do not flood the floor. Use a wet vacuum or mop to absorb the water.
6. Let the floor dry completely.

#### 7. Floor Finish Options:

- A. Proceed to dry buff using a 175 to 350 R.P.M. buffing machine equipped with a white or beige pad depending on the required finish. Or,
  - If a higher luster finish is desired apply two cross coats of TASKI Vision Star or JohnsonDiversey Vectra or Carefree floor finish to the floor using a finish mop.

#### Regular Cleaning

1. Remove surface dust and soil particles by daily sweeping or vacuuming. If necessary, clean with a wet mop, using TASKI R50 or JohnsonDiversey Stride neutral detergent.
2. Restoring the look options:
  - A. Let the floor dry completely then dry buff using a 175 to 350 R.P.M. buffing machine equipped with a white or beige pad depending on required luster. Or,
  - B. Let the floor dry completely then spray buff using TASKI Ultra spray or JohnsonDiversey Snap Back.

#### For Heavily Soiled Areas

1. Remove surface dust and soil particles by vacuuming or brushing.
2. Scrub the floor with TASKI R50 or JohnsonDiversey Stride (225 ml (8 ounces) per 4 liter (1 gallon) of warm water) using a 175 to 350 R.P.M. buffing machine equipped with a red polishing pad or soft nylon brush.
3. Use a wet vacuum or a mop to absorb the residue.
4. Rinse with cold water. Do not flood the floor. Use a wet vacuum or mop to absorb the water.

#### Restoring the look options:

- A. Let the floor dry completely then dry buff using a 175 to 350 R.P.M. buffing machine equipped with a white or beige pad depending on required luster. Or,





## Marathon Oasis & Dura-MED Rolled Rubber MAINTENANCE INSTRUCTIONS

- B) Let the floor dry completely then spray buff using TASKI Ultra Spray or JohnsonDiversey Snap Back.

**Important notice on floor finishes - the application and upkeep of floor finishes dramatically increases the overall cost of maintenance – request a copy of an independent study from American Biltrite (Canada) Ltd. Dura-MED & Oasis rubber flooring does not require the application of floor finishes to protect the floor and should be used for its natural resiliency, however, some users may choose to apply finishes to gain a higher luster.**

These care recommendations are provided as assistance only. We do not assume responsibility for actual work performed. The warranty extends only to the quality and performance of the Marathon Rubber flooring.

**Note:** for additional care and maintenance instructions you may contact TASK or JohnsonDiversey Customer Service directly at 1-800-862-3600 or 1-800- 842-2341.

