



STONESCAPE & VIERA NON-PVC Flooring

MAINTENANCE INSTRUCTIONS

FIRST CLEANING AFTER COMMERCIAL INSTALLATION

IMPORTANT:

Before proceeding to set up your Stonescape flooring, read all instructions carefully and make sure the adhesive has fully cured (see "Curing Times" below).

DO NOT ATTEMPT ANY MAINTENANCE PROCEDURES PRIOR TO 72 HOURS FOLLOWING INSTALLATION.

Floor Appearance

When removing the tiles from the carton it may be noticed that the tiles do not have a consistent appearance. This is a side effect created during the manufacturing and packaging process and **WILL** disappear when the initial recommended maintenance procedure is performed.

1. Sweep and/or dust mop the floor to remove all dirt or grit.
2. Thoroughly scrub the floor clean using a 175-RPM swing machine or auto scrubber equipped with green or blue pad(s) and Taski or JohnsonDiversey RubberSAFE deep cleaner/stripper. Dilute TASKI or JohnsonDiversey RubberSAFE as recommended on the label.
3. Pick up cleaner solution using a wet/dry vacuum or auto scrubber.
4. Rinse the floor thoroughly and pick up the rinse water using a wet/dry vacuum or auto scrubber.
5. Allow the floor to dry completely.

NOTE: Do Not Use A Black or Brown Pad

6. Apply two (2) cross coats of TASKI or JohnsonDiversey Undercover surface primer.

7. After the primer has dried, apply two (2) cross coats of TASKI Vision Star or JohnsonDiversey Vectra or Carefree finish.

(Allow proper drying times between coats as instructed on labels)

Note: For safety reasons, floors will be slippery when wet or contaminated with foreign materials. Promptly clean up spills and foreign materials and use caution tape and/or "wet floor signs".

Regular Maintenance

1. Sweep and/or dust mop the floor daily to remove surface dirt and grit.
2. If necessary damp mop or auto scrub equipped with red pad(s) and TASKI R50 or JohnsonDiversey Stride Neutral cleaner. Dilute as recommended on the label.
3. Spray buff the floor as necessary using TASKI Ultra Spray or JohnsonDiversey Snap Back.

CURING TIMES

Site conditions can greatly affect curing times of the adhesives. Visually check the tile installation to make sure curing of the adhesive is happening by pulling back the corner of the tile. If it will not peel back easily, the curing process is underway. This must not be attempted prior to 24 hours following installation.

We recommend the following adhesive curing guidelines:

- Light traffic for the first 72 hours.
- After 72 hours - moderate to heavy traffic, placement of furniture and rolling traffic.

Note: For additional care and maintenance instructions you may contact TASKI or JohnsonDiversey Customer Service directly at 1-800-862-3600.

